BATTERY CONVERSION CHART

BATTERY VOLTAGE	EVERREADY NUMBER	ENERGIZER NUMBER	DURACELL NUMBER	MAXELL NUMBER	PANASONIC NUMBER	VARTA NUMBER
1.5	301	301	D301	SR43SW	SP301	V301
1.5	303	303	D303	SR44SW	SP303	V303
1.5	309	309	D309	SR754SW	WS6	V309
1.35	313	313	D313	--	NP313	V313
1.5	314	314	--	SR716W	--	--
1.5	315	315	D315	SR716SW	SP315	V315
1.5	317	317	D317	SR516SW	SP317	V317
1.5	319	319	D319	SR527SW	SP319	V319
1.5	321	321	D321	SR616SW	SP321	V321
1.35	323	323	D323	--	WH-6	V323
1.35	325	325	D325	--	WH-1	V325
1.5	328	328	--	--	--	--
1.5	329	329	D329	SR731SW	--	V329
1.5	333	333	--	SR610SW	--	--
1.5	335	335	--	SR512SW	SP335	--
1.5	337	337	--	SR416SW	SR416SW	--
1.5	339	339	--	SR614SW	--	V339
1.5	341	341	--	--	--	V341
1.35	343	343	D343	--	NP343	V343
1.5	344	344	D344	SR1136SW	WS12	V344
1.5	350	350	D350	--	--	V350
1.35	354	354	D354	--	--	V354
1.5	357	357	D357	SR44W	SP357	V357
1.5	361	361	D361	SR721W	SP361	V361
1.5	362	362	D362	SR721SW	SP362	V362
1.5	364	364	D364	SR621W	SP364	V364
1.5	365	365	--	SR1116W	--	--
1.5	366	366	D366	SR1116SW	--	V366
1.5	370	370	D370	SR920W	SP370	V370
1.5	371	371	D371	SR920SW	SP371	V371
1.5	372	372	--	SR916W	SP372	--
1.5	373	373	D373	SR916SW	SP373	V373
1.5	376	376	--	SR626W	SP376	--
1.5	377	377	D377	SR626SW	SP377	V377
1.5	379	379	D379	SR521SW	SP379	V379
1.5	381	381	D381	SR1120SW	--	V381
1.5	384	384	D384	SR41SW	SP384	V384
1.5	386	386	D386	SR43W	SP386	V386
1.35	387	387	D387	--	--	V387
1.35	388	388	D388	--	--	V388
1.5	389	389	D389	SR1130W	SP389	V389
1.5	390	390	D390	SR1130SW	WS-10	V390
1.5	391	391	D391	SR1120W	SP391	V391
1.5	392	392	D392	SR41W	SP392	V392
1.5	393	393	D393	SR754W	SP393	V393
1.5	394	394	D394	SR936SW	--	V394
1.5	395	395	D395	SR927SW	SP395	V395
1.5	396	396	D396	SR726W	SP396	V396
1.5	397	397	D397	SR726SW	SP397	V397
1.5	399	399	D399	SR927W	SP399	V399

ENERGIZER IS THE MOST POPULAR WATCH BATTERY

LITHIUM

EVERREADY NUMBER	ENERGIZER NUMBER	DURACELL NUMBER	MAXELL NUMBER	PANASONIC NUMBER	VARTA NUMBER
--	--	--	--	CR1025	--
ECR1216	ECR1216	--	--	CR1216	--
ECR1220	ECR1220	DL1220	CR1220	CR1220	CR1220
ECR1225	ECR1225	--	--	--	--
ECR1616	ECR1616	--	CR1616	CR1616	--
ECR1620	ECR1620	DL1620	CR1620	CR1620	CR1620
ECR2012	ECR2012	--	CR2012	CR2012	--
ECR2016	ECR2016	DL2016	CR2016	CR2016	CR2016
ECR2025	ECR2025	DL2025	CR2025	CR2025	CR2025
ECR2032	ECR2032	DL2032	CR2032	CR2032	CR2032
ECR2320	ECR2320	--	--	CR2320	--
ECR2430	ECR2430	DL2430	CR2430	--	CR2430

Copyright © WWW.JEWELRY-SECRETS.COM

Some Watch Batteries are interchangeable, like 376 & 377. If your Watch takes either of these Cells, you can use 376 or 377 in your Watch. Same with batteries 396 & 397!

361 & 362 will work for each other. As well as 395 & 399! Companies like Energizer & Duracell will state right on the packaging what numbers it will work for.
(See picture! 303 & 357 are the same!)

CR1025 is made by Panosonic and goes by a couple of different names: BR1025, P031 ND, and P031 and has no conversion that I know of!

Copyright © WWW.JEWELRY-SECRETS.COM